

Explosionproof Batch Counter

MODEL: EL7320

GENERAL SPECIFICATION GS.No.GEB404E-3

■ GENERAL

Combined with a flowmeter and valve, the batch counter measures a predetermined amount of process fluid in batching operations. As a piece of explosion proof equipment, the batch counter is suitable for outdoor applications. It saves time and effort in various processes, such as blending materials, dosing with additives, transferring fluid from one tank to another, or shipping process, mainly in chemical, food, and paint industries.



■ FEATURES

1. Flameproof rat

The batch counter is flameproof rated (Ex d IIB T4) and can be implemented in hazardous locations Zone 1 and Zone 2.

2. Easy to opera

- (1) Parameter settings, start, stop, and reset can be done by pressing large pushbuttons on the front panel.
- (2) Improved visibility for outdoor and/or remote applications with large LED display (7-segment, 25.4mm).
- (3) With each operation function (start, stop, and reset) and parameter setting function assigned separately to different buttons, erroneous setting will be prevented.

3. Erroneous setting protecti

Accidental erroneous settings can be prevented by selecting predefined batch settings with the cam switch. Up to five batch settings are available.

4. Accurate batching control

- (1) The valve can be programmed to open and close in two stages for precise batch control.
- (2) Setting anticipated overshoot enables the batch counter to correct the overshoot caused by response lag from the valve.

5. Feasible system constructi

With the ability to operate by remote commands (start, stop, and reset) and batch-end output function, interlocking with other process control systems can be easily done.

6. Increased process safe

- (1) The batch counter controls a valve in two stages (two-stage open, two-stage close). This prevents static inside pipes or tank at the start of operation, and hydraulic shock at valve closure.
- (2) An alarm signal can be generated when there is no pulse input or the batch counter receives a pulse exceeding the batch setting for any reason.

7. Reliable and easy to mainta

- (1) This equipment is highly reliable and easily serviced since internal electronics are assembled as units.
- (2) Every input/output system is isolated by photocouplers and/or relays.
- (3) FeRAM storage retains the total count and other parameters when the power is turned off.

Архангельск (8182)63-90-72 Астана +7(7172)727-132 Белгород (4722)40-23-64 Брянск (4832)59-03-52 Владивосток (423)249-28-31 Волгоград (844)278-03-48 Вологда (8172)26-41-59 Воронеж (473)204-51-73 Екатеринбург (343)384-55-89 Иваново (4932)77-34-06 Ижевск (3412)26-03-58 Казань (843)206-01-48 Калининград (4012)72-03-81 Калуга (4842)92-23-67 Кемерово (3842)65-04-62 Киров (8332)68-02-04 Краснодар (861)203-40-90 Красноярск (391)204-63-61 Курск (4712)77-13-04 Липецк (4742)52-20-81 Магнитогорск (3519)55-03-13 Москва (495)268-04-70 Мурманск (8152)59-64-93 Набережные Челны (8552)20-53-41 Нижний Новгород (831)429-08-12 Новокузнецк (3843)20-46-81 Новосибирск (383)227-86-73 Орел (4862)44-53-42 Оренбург (3532)37-68-04 Пенза (8412)22-31-16 Пермь (342)205-81-47 Ростов-на-Дону (863)308-18-15 Рязань (4912)46-61-64 Самара (846)206-03-16 Санкт-Петербург (812)309-46-40 Саратов (845)249-38-78 Смоленск (4812)29-41-54 Сочи (862)225-72-31 Ставрополь (8652)20-65-13 Тверь (4822)63-31-35 Томск (3822)98-41-53 Тула (4872)74-02-29 Тюмень (3452)66-21-18 Ульяновск (8422)24-23-59 Уфа (347)229-48-12 Челябинск (351)202-03-61 Череповец (8202)49-02-64 Ярославль (4852)69-52-93


■ GENERAL SPECIFICATIONS

		Item			Description	on							
Ty	pe o	f operation	Pulse addition										
		<u> </u>	Total count: 6-digit, 7-segment, 25	.4mm, Red LED									
≥	Di	splay	Batch setting: 6-digit, 7-segment,	•	(displays grand total	in 9-digit by ▼ button operation)							
Display			Channel number: 2-digit, 7-segme		· · · · ·								
ﻕ			LEDs: RUN (YEL)/ END (GRN)/ A			·							
	Op	peration status indicator	×10 (ORG)/ ×100 (ORG)/ N	//V (RED)/ SV (R	ED)/ PUMP (RED)								
Buttons	Ch	annel select	Explosionproof cam switch with 6	notches									
₽	Pu	shbutton	φ30 explosionproof pushbuttons:	SET(BLK)/ ▼ (BI	_K)/ ▲ (BLK)/ STOP	(RED)/ RESET (YEL)/ START (GR	N)						
Bu	zze	•	φ30 explosionproof buzzer for ala	rm									
		Pulse type	Example Transmitters	Power to	Transmitter	Signal Level	Freq. Response						
		2-wire/12V DC 3-wire contact-closure pulse	PG20	13.5VDC		12VDC ON/OFF	Max 50Hz						
	Ħ	2-wire/12V DC 3-wire open collector pulse	Coriolis flowmeter/NPG60A (E3) FLOWPET-EG	13.5VDC		(Input load resistance: 10kΩ)							
	Pulse Input	2-wire/12V DC 3-wire voltage pulse	PG30 NPG60A (F)	13.5VDC	Current capacity: 55mA	"1": more than 5VDC "0": less than 1.5VDC							
Input Signal	Pul	12V DC 2-wire current pulse	PG30S	13.5VDC	(with short-circuit protection)	"1": 20mADC "0": 4mADC Input load resistance: 510Ω	Max 3kHz (*1)						
lubut (24V DC 2-wire current pulse	PA14/15/25 ULTRA OVAL NPG60A (E)	24VDC		"1": 20mADC "0": 4mADC Input load resistance: 250Ω							
		Start	Form "a" contact										
	put	Reset	Form "a" contact		Contact signal/Open collector signal								
	Remote Input	Stop	Form "b" contact		Contact signal "ON" width: 200msec Instant signal "OFF" width: 200msec								
	mot	Channel select	BCD combination of 1 /2 /4										
	æ	Set	Form "a" contact										
		InterLock	Form "a" contact normally short-ci	rcuited									
	Me	eter factor setting	0.00010 to 1.99999 (Default: 1.00000)										
	_	out pulse freq.	Software-defined frequency: 1/1, 1	1/10, 1/100 (Defa	ault: 1/1)								
	Οι	itput pulse freq.	Software-defined frequency: 1/1, 1/10, 1/100 (Default: 1/1)										
ē		Batch setting	6 channels: 0 to 999999 counts (Only Ch.1 can be changed on the front panel.)										
etti	동	Initial setting	0 to 9999 counts (Default: 80)										
ie S	Batch	Final setting	0 to 9999 counts (Default: 80)										
Parameter Setting		Anticipated overshoot	0 to 99 counts (Default: 2)										
Pare	_	Batch-end monitor setting	0 to 99 sec (Default: 5) 0 to 9999 sec (Default: 30)										
_	Pu	mp output timer	0 to 9999 sec (Default: 30) 0 to 999 sec (Default: 5)										
	Alarm	Missing pulse interval Overshoot	0 to 99 sec (Default: 5) 0 to 99 counts (Default: 2)										
	Ala		to 99 counts (Default: 2)										
	Hr	Leak per limit flow signal	Full-open signal MV										
<u>_</u>	·	rtial flow signal	1-stage open signal SV			pply voltage (max. 0.5A) or relay c ion chart for ON/OFF of form "a" c							
ig		mp control signal	Relay contact (250V AC 0.5A) form "c" contact										
Output Signal		tch-end signal	Static relay (250V AC 0.1A) form "a" contact										
其		arm signal	Relay contact (250V AC 0.5A) form										
		Ise signal	Open collector NPN transistor out		mA) Pulse width: 15	Dusec/ 1msec/ 50msec max. 3kHz	z (*2)						
Po		failure backup	Saves data to FeRAM at power-of		,								
Po	wer	source	100/110VAC or 200/220VAC 50/60		roltage: within ±10% (of rated voltage)							
Po	wer	consumption	30VA (Power consumed by the batch counter only, excluding power supply for MV/SV.)										
An	nbie	nt temperature	-20 to +50°C										
Co	nfig	uration	Explosionproof rating: Flameproof Ex d IIB T4 (%3)										
Ins	tall	ation	Wall-mount or Stanchion										
Fin	nish		Munsell 2.5PB 5/8, glossy (standa	ırd)									
Но	usii	ng material	Aluminum casting (Stanchion: stee	el)									
Ou	tlin	e dimensions	300 (W) ×360 (H) ×247 (D) (batch	counter body on	ly)								
We	eigh	t	Approx. 20kg (batch counter body	only)									
No	ise	resistance	EMC EN55011 EN61000-6-2										
			stance and specification of the cable										

 $[\]ensuremath{\text{*1}}\xspace$ Varies depending on transmission distance and specification of the cable.

^{*1:} Varies depending on transmission distance and specification of the cable.
(e.g. 100m when open collector pulse with CVVS 1.25sq cable)
*2: When 150µsec output is selected, transmission distance will be limited depending on cable specification and receiving circuit.
(e.g. with CVVS 1.25sq cable and collector current 20mA, the transmission distance will be limited to 500m.)
*3: Specific pressure-tight packing cable glands are required if the batch counter is to be used for explosionproof purpose.
Five explosionproof plugs are provided with the batch counter.

■ OPERATION CHART



As you press the START button, the valve opens to a predefined position. The valve fully opens when flow of the fluid reaches a certain amount (where Initial setting = Point A to Point B). As it reaches Point C, the valve automatically closes to a predefined position. At Point D, a signal will be generated for shutting the valve, but because of valve operation delay, the valve fully closes at Point E.

The amount processed from Point D to Point E is anticipated overshoot. Batch setting (Point D) can be configured with the corrected value.

Even if the valve shuts off at constant time periods, the actual point for valve to be shut off may fluctuate from Point E as line pressure varies.

If overshoot exceeds Point E, an alarm will be set off. Note that the positions of valve (for Point A \rightarrow B and C \rightarrow D) need to be determined beforehand.

■ PRODUCT CODE EXPLANATION

• Batch Counter Body

	ii counter body														
												Description			
	1 2 3 4 5 6 -	7	8	9	10	11	12	13	14)	15)	16	2000.1.p.101.			
Model	E L 7 3 2 0 -											Explosionproof batch counter			
		1										100VAC 50/60Hz			
		2										200VAC 50/60Hz			
Power		3										110VAC 50/60Hz			
		4										220VAC 50/60Hz			
		9										Other			
			2									2-wire, 12VDC 3-wire contact-closure pulse			
			3									2-wire, 12VDC 3-wire voltage pulse			
Flow In			4									24VDC 2-wire current pulse (4/20mA DC)			
FIOW III	put		5									12VDC 2-wire current pulse			
			6									2-wire, 12VDC 3-wire open collector pulse			
			9									Other			
A dditio	nal Function			1								Standard			
Additio	Additional Function 9											Other			
					1							Same as supply voltage			
Valve C	peration Signal				2							Contant-closure output			
					9							Other			
						1						Wall-mount			
Installa	tion					2						Stanchion			
					Ī	9						Other			
Sunsha							0					Not furnished			
Sunsna	iue						1					Furnished			
Hood								0				Not furnished			
пооа								1				Furnished			
Dubba	Button Cover								0			Not furnished			
nubbei	Duttoff Cover							[1			Furnished			
Finish										1		Munsell 2.5PB5/8, glossy			
Finish									Ì	9		Other			
Version	Version A										Α				


• Code Explanation for Pressure-tight Packing Cable Gland

(This apparatus must be arranged for explosionproof purpose.)


Itom				Со	de E	Expl	anat	ion				Description		
Item	1	2	3	4	(5)	_	7	8	9	10	11)	Description		
Model H P N 2 1 -												Cable gland		
							R	0	8	-	О	More than 6mm up to 8mm		
Applica	Applicable Cable O.D.									-	С	More than 8mm up to 10mm		
				R	1	2	-	С	More than 10mm up to 12mm					

Itam				Со	de E	Expl	anat	ion				Description				
Item	1	2	3	4	(5)	-	7	8	9	10	11)	Description				
Model	del H P N 2 2 -											Cable gland				
Applicab	R 1 4 - C										More than 12mm up to 14mm					
Applicat	Applicable Cable O.D. R 1 6 - C											More than 14mm up to 16mm				

■ OUTLINE DIMENSIONS



■ BLOCK DIAGRAM



■ EXTERNAL CONNECTION TERMINALS

Terminal Block

TB02 (M3.5 touchdown structure)

1		3	5	5	7	, (9	1	1	13	1	5	1	7	19	2	1	2	3	2	5	2	7	
	2	4	1	6	3	8	1	0	12	2 1	4	1	6	18	3 2	20	2	2	2	4	2	ô	2	8




Connection Terminals

TB01

Signal	No.	Description							
	1	G	Ground Terminal (*1)						
Power	2	AC (L)	100/110V AC						
	3	AC (N)	200/220V AC						


*1: To prevent electric shock, fire, and interference from exogenous noise, make sure to ground the terminal.

TB02




■ OPTIONS

◆ Stanchion




◆ Sunshade



Protects the bacth counter from direct sunlight and rain. Material: SUS unfinished

◆ Hood



Covers over the display for better visibility.

Material: SUS Finish : N1.5 matte

◆ Rubber Cover for Pushbuttons




Ensures better waterproof performance by covering the pushbuttons.

◆ Pressure-tight packing cable gland

A wiring apparatus used for leading cables (rubber/plastic) into the counter

		Model		HPN21-		HPN	122-		
		Model	R8 - C	R10 - C	R12 - C	R14 - C	R16 - C		
	Appl	icable cable O.D.	6 - 8	8 - 10	10 - 12	12 - 14	14 - 16		
		O.D.		21	25				
		I.D.	8	10	12	14	16		
		Thickness	6.5	5.5	4.5	5.5	4.5		
ē	Leng	th before compression (L)		34		3	4		
Packing	Leng	th after compression (L)		Min. 25.5		Min.	25.5		
<u>a</u>	Effe	ctive compressibility	1	0% appro	х.	10% a	pprox.		
	Box	I.D. (V)		21.5		25	5.5		
	ď	I.D. (T)		44		4	4		
		Depth (U)		17.5		17	'.5		
		Α		38		4	2		
L		В		36		40			
		N.D.		G 3/4		G 3/4			
С		Pitch		1.8143		1.8	143		
		Grade		В		В			
		D		G 1/2		G 3/4			
		E		41.5		41.5			
		F		25		25			
L		G		(78)		(78)			
		Н		13		17			
		J		R14		R	12		
		K	9	11	13	15	17		
		M		21			5		
		N		13			7		
		0		5		Ę			
		P (min.)	4.5	5.5	6.5	11 12			
		Q		8		8			
		R		28		32			
		S		21		2	5		



■ PLEASE SUPPLY THE FOLLOWING INFORMATION WHEN YOU INQUIRE:

	Item	Specification
1.	Product model	EL7320
2.	Quantity	units
3.	Finish	☐ Munsell 2.5PB 5/8, glossy (standard) ☐
4.	Application label	Material: Clear acrylic Engraving: Black-on-white Location: Front top Placement: Adhesive Size: 12.5mm × 80mm × 2t Font: Round Gothic Font size: 24Q
5.	Power supply	VAC
6.	Input pulse	Pulse type:
7.	Output pulse	Pulse unit: same as input pulse Pulse width: ☐ 150µsec ☐ 1msec ☐ 50msec
8.	Valve output	☐ Same as power supply voltage ☐ Relay contact
9.	Batch control	☐ 2-stage open, 2-stage close ☐ 2-stage open, 1-stage close ☐ 1-stage open, 1-stage close
10.	Options	Stanchion Height ☐ 1500mm (standard) ☐ Sunshade ☐ Hood ☐ Pushbutton covers (6pcs) ☐ Pressure-tight packing cable glands (Up to 5pcs) Applicable cable diameter: ☐ 6 - 8mm (pcs) ☐ 8 - 10mm (pcs) ☐ 10 - 12mm (pcs)
11.	Special notes	□ 6 - 8mm (pcs) □ 8 - 10mm (pcs) □ 10 - 12mm (pcs) □ 12 - 14mm (pcs)

Архангельск (8182)63-90-72 Астана +7(7172)727-132 Белгород (4722)40-23-64 Брянск (4832)59-03-52 Владивосток (423)249-28-31 Волгоград (844)278-03-48 Вологда (8172)26-41-59 Воронеж (473)204-51-73 Екатеринбург (343)384-55-89 Иваново (4932)77-34-06 Ижевск (3412)26-03-58 Казань (843)206-01-48 Калининград (4012)72-03-81 Калуга (4842)92-23-67 Кемерово (3842)65-04-62 Киров (8332)68-02-04 Краснодар (861)203-40-90 Красноярск (391)204-63-61 Курск (4712)77-13-04 Липецк (4742)52-20-81 Магнитогорск (3519)55-03-13 Москва (495)268-04-70 Мурманск (8152)59-64-93 Набережные Челны (8552)20-53-41 Нижний Новгород (831)429-08-12 Новокузнецк (3843)20-46-81 Новосибирск (383)227-86-73 Орел (4862)44-53-42 Оренбург (3532)37-68-04 Пенза (8412)22-31-16 Пермь (342)205-81-47 Ростов-на-Дону (863)308-18-15 Рязань (4912)46-61-64 Самара (846)206-03-16 Санкт-Петербург (812)309-46-40 Саратов (845)249-38-78 Смоленск (4812)29-41-54 Сочи (862)225-72-31 Ставрополь (8652)20-65-13 Тверь (4822)63-31-35 Томск (3822)98-41-53 Тула (4872)74-02-29 Тюмень (3452)66-21-18 Ульяновск (8422)24-23-59 Уфа (347)229-48-12 Челябинск (351)202-03-61 Череповец (8202)49-02-64 Ярославль (4852)69-52-93